



-A47  
/114044.a.1  
/114044.a.1

## Eingänge




Auswertemodul	Slot 1 / Byte 0	
	E356.0	<input type="checkbox"/> T (Türstellung)
	E356.1	<input type="checkbox"/> R (Riegelstellung)
	E356.2	<input type="checkbox"/> Z (Zuhaltung)
	E356.3	<input type="checkbox"/> n.c.
	E356.4	<input type="checkbox"/> n.c.
	E356.5	<input type="checkbox"/> n.c.
	E356.6	<input type="checkbox"/> SK (T UND R)
Diagnosemodul	Slot 2 / Byte 0	
	E357.0	<input type="checkbox"/> Meldung liegt an. Profisafe
	E357.1	<input type="checkbox"/> Meldung 274(4)
	E357.2	<input type="checkbox"/> n.c.
	E357.3	<input type="checkbox"/> n.c.
	E357.4	<input type="checkbox"/> n.c.
	E357.5	<input type="checkbox"/> n.c.
	E357.6	<input type="checkbox"/> n.c.
PROFIsafe	Slot 3 / Byte 0	
	E358.0	<input type="checkbox"/> n.c.
	E358.1	<input type="checkbox"/> n.c.
	E358.2	<input type="checkbox"/> T (Türstellung)
	E358.3	<input type="checkbox"/> R (Riegelstellung)
	E358.4	<input type="checkbox"/> Z (Zuhaltung)
	E358.5	<input type="checkbox"/> n.c.
	E358.6	<input type="checkbox"/> n.c.
	E358.7	<input type="checkbox"/> n.c.
	Slot 3 / Byte 1	
	E359.0	<input type="checkbox"/> SK (T UND R)
	E359.1	<input type="checkbox"/> ÜK (T UND R UND Z)
	E359.2	<input type="checkbox"/> n.c.
	E359.3	<input type="checkbox"/> n.c.
	E359.4	<input type="checkbox"/> n.c.
	E359.5	<input type="checkbox"/> n.c.
	E359.6	<input type="checkbox"/> n.c.
	E359.7	<input type="checkbox"/> n.c.

## Ausgänge

Auswertemodul	Slot 1 / Byte 0	
	A316.0	<input type="checkbox"/> Zuhaltemagnet - Steuerspannung ein
	A316.1	<input type="checkbox"/> n.c.
	A316.2	<input type="checkbox"/> n.c.
	A316.3	<input type="checkbox"/> n.c.
	A316.4	<input type="checkbox"/> n.c.
	A316.5	<input type="checkbox"/> n.c.
	A316.6	<input type="checkbox"/> n.c.
Diagnosemodul	Slot 2 / Byte 0	
	A317.0	<input type="checkbox"/> Gerätediagnose: Meldung quittieren
	A317.1	<input type="checkbox"/> Reset MGB Zuhaltmodul: Meldung quittieren
	A317.2	<input type="checkbox"/> n.c.
	A317.3	<input type="checkbox"/> n.c.
	A317.4	<input type="checkbox"/> n.c.
	A317.5	<input type="checkbox"/> n.c.
	A317.6	<input type="checkbox"/> n.c.
PROFIsafe	Slot 4 / Byte 0	
	A318.0	<input type="checkbox"/> Zuhaltmagnet - Steuerspannung ein
	A318.1	<input type="checkbox"/> n.c.
	A318.2	<input type="checkbox"/> n.c.
	A318.3	<input type="checkbox"/> n.c.
	A318.4	<input type="checkbox"/> n.c.
	A318.5	<input type="checkbox"/> n.c.
	A318.6	<input type="checkbox"/> n.c.
	A318.7	<input type="checkbox"/> n.c.
	Slot 4 / Byte 1	
	A319.0	<input type="checkbox"/> n.c.
	A319.1	<input type="checkbox"/> n.c.
	A319.2	<input type="checkbox"/> n.c.
	A319.3	<input type="checkbox"/> n.c.
	A319.4	<input type="checkbox"/> n.c.
	A319.5	<input type="checkbox"/> n.c.
	A319.6	<input type="checkbox"/> n.c.
	A319.7	<input type="checkbox"/> n.c.

**EUCHNER** | MGB

114044  
MGB-L2B-PNA-R



EUC\MGB\MGB\_PNA\_R\_122008.ema  
Variant B  
Overview  
V1.0  
==Safety==Safety\_systems++MGB\_PN+PNA-122008/114044.c

