



EUC\MGB\MGB_PNC_L_114412.ema
Variant A
Multi-line
V2.0
==Safety=Safety_systems++MGB_PN+PNC-114412/115421.a



EUC\MGB\MGB_PNC_L_114412.ema
Variant B
Multi-line
V2.0
==Safety=Safety_systems++MGB_PN+PNC-114412/115421.a



-A76

/115421.a.1

/115421.a.1

Eingänge

Busmodul	Slot 1 / Byte 0	Diagnosemodul	Slot 4 / Byte 0
	E1196.0 <input type="checkbox"/> S90 Taster E1196.1 <input type="checkbox"/> S91 Taster E1196.2 <input type="checkbox"/> n.c. E1196.3 <input type="checkbox"/> n.c. E1196.4 <input type="checkbox"/> n.c. E1196.5 <input type="checkbox"/> S95 Taster E1196.6 <input type="checkbox"/> n.c. E1196.7 <input type="checkbox"/> n.c.		E1200.0 <input type="checkbox"/> Meldung liegt an. Profisafe E1200.1 <input type="checkbox"/> Meldung 274(4) E1200.2 <input type="checkbox"/> n.c. E1200.3 <input type="checkbox"/> Meldung 272(2) oder 273(2) E1200.4 <input type="checkbox"/> n.c. E1200.5 <input type="checkbox"/> n.c. E1200.6 <input type="checkbox"/> n.c. E1200.7 <input type="checkbox"/> Meldung 274(1)
Auswertemodul	Slot 1 / Byte 1	PROFIsafe	Slot 5 / Byte 0
	E1197.0 <input type="checkbox"/> n.c. E1197.1 <input type="checkbox"/> n.c. E1197.2 <input type="checkbox"/> n.c. E1197.3 <input type="checkbox"/> n.c. E1197.4 <input type="checkbox"/> n.c. E1197.5 <input type="checkbox"/> n.c. E1197.6 <input type="checkbox"/> n.c. E1197.7 <input type="checkbox"/> n.c.		E1201.0 <input type="checkbox"/> n.c. E1201.1 <input type="checkbox"/> Zustimmtaster E1201.2 <input type="checkbox"/> T (Türstellung) E1201.3 <input type="checkbox"/> R (Riegelstellung) E1201.4 <input type="checkbox"/> Z (Zuhaltung) E1201.5 <input type="checkbox"/> n.c. E1201.6 <input type="checkbox"/> n.c. E1201.7 <input type="checkbox"/> n.c.
Zustimmtastermod.	Slot 2 / Byte 0		Slot 5 / Byte 1
	E1198.0 <input type="checkbox"/> T (Türstellung) E1198.1 <input type="checkbox"/> R (Riegelstellung) E1198.2 <input type="checkbox"/> Z (Zuhaltung) E1198.3 <input type="checkbox"/> n.c. E1198.4 <input type="checkbox"/> n.c. E1198.5 <input type="checkbox"/> n.c. E1198.6 <input type="checkbox"/> SK (T UND R) E1198.7 <input type="checkbox"/> ÜK (T UND R UND Z)		E1202.0 <input type="checkbox"/> SK (T UND R) E1202.1 <input type="checkbox"/> ÜK (T UND R UND Z) E1202.2 <input type="checkbox"/> n.c. E1202.3 <input type="checkbox"/> n.c. E1202.4 <input type="checkbox"/> n.c. E1202.5 <input type="checkbox"/> n.c. E1202.6 <input type="checkbox"/> n.c. E1202.7 <input type="checkbox"/> n.c.
	Slot 3 / Byte 0		
	E1199.0 <input type="checkbox"/> Zustimmtaster in Stellung "Zustimmung" E1199.1 <input type="checkbox"/> n.c. E1199.2 <input type="checkbox"/> n.c. E1199.3 <input type="checkbox"/> n.c. E1199.4 <input type="checkbox"/> n.c. E1199.5 <input type="checkbox"/> Zummittaster Taste + E1199.6 <input type="checkbox"/> Zummittaster Taste - E1199.7 <input type="checkbox"/> Zummittaster Haltererkennung		

EUCHNER




MGB

115421

MGB-L1B-PNC-L

Ausgänge

Busmodul	Slot 1 / Byte 0	Diagnosemodul	Slot 4 / Byte 0
	A1057.0 <input type="checkbox"/> LED; H90 A1057.1 <input type="checkbox"/> LED; H91 A1057.2 <input type="checkbox"/> n.c. A1057.3 <input type="checkbox"/> n.c. A1057.4 <input type="checkbox"/> n.c. A1057.5 <input type="checkbox"/> LED; H95 A1057.6 <input type="checkbox"/> n.c. A1057.7 <input type="checkbox"/> n.c.		A1060.0 <input type="checkbox"/> Gerätediagnose: Meldung quittieren A1060.1 <input type="checkbox"/> Reset MGB Zuhaltmodul: Meldung quittieren A1060.2 <input type="checkbox"/> n.c. A1060.3 <input type="checkbox"/> n.c. A1060.4 <input type="checkbox"/> n.c. A1060.5 <input type="checkbox"/> n.c. A1060.6 <input type="checkbox"/> n.c. A1060.7 <input type="checkbox"/> n.c.
Auswertemodul	Slot 2 / Byte 0	PROFIsafe	Slot 5 / Byte 0
	A1058.0 <input type="checkbox"/> Zuhaltmagnet - Steuerspannung ein A1058.1 <input type="checkbox"/> n.c. A1058.2 <input type="checkbox"/> n.c. A1058.3 <input type="checkbox"/> n.c. A1058.4 <input type="checkbox"/> n.c. A1058.5 <input type="checkbox"/> n.c. A1058.6 <input type="checkbox"/> n.c. A1058.7 <input type="checkbox"/> n.c.		A1061.0 <input type="checkbox"/> Zuhaltmagnet - Steuerspannung ein A1061.1 <input type="checkbox"/> n.c. A1061.2 <input type="checkbox"/> n.c. A1061.3 <input type="checkbox"/> n.c. A1061.4 <input type="checkbox"/> n.c. A1061.5 <input type="checkbox"/> n.c. A1061.6 <input type="checkbox"/> n.c. A1061.7 <input type="checkbox"/> n.c.
Zustimmtastermod.	Slot 3 / Byte 0		Slot 5 / Byte 1
	A1059.0 <input type="checkbox"/> Zustimmtaster Beleuchtung für Taste + A1059.1 <input type="checkbox"/> Zustimmtaster Beleuchtung für Taste - A1059.2 <input type="checkbox"/> n.c. A1059.3 <input type="checkbox"/> n.c. A1059.4 <input type="checkbox"/> n.c. A1059.5 <input type="checkbox"/> n.c. A1059.6 <input type="checkbox"/> n.c. A1059.7 <input type="checkbox"/> n.c.		A1062.0 <input type="checkbox"/> n.c. A1062.1 <input type="checkbox"/> n.c. A1062.2 <input type="checkbox"/> n.c. A1062.3 <input type="checkbox"/> n.c. A1062.4 <input type="checkbox"/> n.c. A1062.5 <input type="checkbox"/> n.c. A1062.6 <input type="checkbox"/> n.c. A1062.7 <input type="checkbox"/> n.c.



EUC\MGB\MGB_PNC_L_114412.ema
Variant B
Overview
V2.0
==Safety==Safety_systems++MGB_PN+PNC-114412/115421.c

