



EUC\MGB\MGB_PNC_R_114412.ema
Variant A
Multi-line
V2.0
==Safety=Safety_systems++MGB_PN+PNC-114412/114398.a



EUC\MGB\MGB_PNC_R_114412.ema
Variant B
Multi-line
V2.0
==Safety=Safety_systems++MGB_PN+PNC-114412/114398.a



-A63

/114398.a.1

/114398.a.1

Eingänge

Busmodul	Slot 1 / Byte 0		Diagnosemodul	Slot 4 / Byte 0	
	E1105.0	<input type="checkbox"/> S90 Taster		E1109.0	<input type="checkbox"/> Meldung liegt an. Profisafe
	E1105.1	<input type="checkbox"/> S91 Taster		E1109.1	<input type="checkbox"/> Meldung 274(4)
	E1105.2	<input type="checkbox"/> n.c.		E1109.2	<input type="checkbox"/> n.c.
	E1105.3	<input type="checkbox"/> n.c.		E1109.3	<input type="checkbox"/> Meldung 272(2) oder 273(2)
	E1105.4	<input type="checkbox"/> n.c.		E1109.4	<input type="checkbox"/> n.c.
	E1105.5	<input type="checkbox"/> S95 Taster		E1109.5	<input type="checkbox"/> n.c.
	E1105.6	<input type="checkbox"/> n.c.		E1109.6	<input type="checkbox"/> n.c.
	E1105.7	<input type="checkbox"/> n.c.		E1109.7	<input type="checkbox"/> Meldung 274(1)
	Slot 1 / Byte 1			Slot 5 / Byte 0	
Auswertemodul	E1106.0	<input type="checkbox"/> n.c.	PROFIsafe	E1110.0	<input type="checkbox"/> n.c.
	E1106.1	<input type="checkbox"/> n.c.		E1110.1	<input type="checkbox"/> Zustimmtaster
	E1106.2	<input type="checkbox"/> n.c.		E1110.2	<input type="checkbox"/> T (Türstellung)
	E1106.3	<input type="checkbox"/> n.c.		E1110.3	<input type="checkbox"/> R (Riegelstellung)
	E1106.4	<input type="checkbox"/> n.c.		E1110.4	<input type="checkbox"/> Z (Zuhaltung)
	E1106.5	<input type="checkbox"/> n.c.		E1110.5	<input type="checkbox"/> n.c.
	E1106.6	<input type="checkbox"/> n.c.		E1110.6	<input type="checkbox"/> n.c.
	E1106.7	<input type="checkbox"/> n.c.		E1110.7	<input type="checkbox"/> n.c.
Slot 2 / Byte 0			Slot 5 / Byte 1		
Auswertemodul	E1107.0	<input type="checkbox"/> T (Türstellung)	PROFIsafe	E1111.0	<input type="checkbox"/> SK (T UND R)
	E1107.1	<input type="checkbox"/> R (Riegelstellung)		E1111.1	<input type="checkbox"/> ÜK (T UND R UND Z)
	E1107.2	<input type="checkbox"/> Z (Zuhaltung)		E1111.2	<input type="checkbox"/> n.c.
	E1107.3	<input type="checkbox"/> n.c.		E1111.3	<input type="checkbox"/> n.c.
	E1107.4	<input type="checkbox"/> n.c.		E1111.4	<input type="checkbox"/> n.c.
	E1107.5	<input type="checkbox"/> n.c.		E1111.5	<input type="checkbox"/> n.c.
	E1107.6	<input type="checkbox"/> SK (T UND R)		E1111.6	<input type="checkbox"/> n.c.
	E1107.7	<input type="checkbox"/> ÜK (T UND R UND Z)		E1111.7	<input type="checkbox"/> n.c.
Slot 3 / Byte 0					
Zustimmtastermod.	E1108.0	<input type="checkbox"/> Zustimmtaster in Stellung "Zustimmung"			
	E1108.1	<input type="checkbox"/> n.c.			
	E1108.2	<input type="checkbox"/> n.c.			
	E1108.3	<input type="checkbox"/> n.c.			
	E1108.4	<input type="checkbox"/> n.c.			
	E1108.5	<input type="checkbox"/> Zummistaster Taste +			
	E1108.6	<input type="checkbox"/> Zummistaster Taste -			
	E1108.7	<input type="checkbox"/> Zummistaster Haltererkennung			

EUCHNER




MGB

114398

MGB-L2B-PNC-R

Ausgänge

Busmodul	Slot 1 / Byte 0		Diagnosemodul	Slot 4 / Byte 0	
	A979.0	<input type="checkbox"/> LED; H90		A982.0	<input type="checkbox"/> Gerätediagnose: Meldung quittieren
	A979.1	<input type="checkbox"/> LED; H91		A982.1	<input type="checkbox"/> Reset MGB Zuhaltmodul: Meldung quittieren
	A979.2	<input type="checkbox"/> n.c.		A982.2	<input type="checkbox"/> n.c.
	A979.3	<input type="checkbox"/> n.c.		A982.3	<input type="checkbox"/> n.c.
	A979.4	<input type="checkbox"/> n.c.		A982.4	<input type="checkbox"/> n.c.
	A979.5	<input type="checkbox"/> LED; H95		A982.5	<input type="checkbox"/> n.c.
	A979.6	<input type="checkbox"/> n.c.		A982.6	<input type="checkbox"/> n.c.
	A979.7	<input type="checkbox"/> n.c.		A982.7	<input type="checkbox"/> n.c.
	Auswertemodul	Slot 2 / Byte 0		PROFIsafe	Slot 5 / Byte 0
A980.0		<input type="checkbox"/> Zuhaltmagnet - Steuerspannung ein	A983.0		<input type="checkbox"/> Zuhaltmagnet - Steuerspannung ein
A980.1		<input type="checkbox"/> n.c.	A983.1		<input type="checkbox"/> n.c.
A980.2		<input type="checkbox"/> n.c.	A983.2		<input type="checkbox"/> n.c.
A980.3		<input type="checkbox"/> n.c.	A983.3		<input type="checkbox"/> n.c.
A980.4		<input type="checkbox"/> n.c.	A983.4		<input type="checkbox"/> n.c.
A980.5		<input type="checkbox"/> n.c.	A983.5		<input type="checkbox"/> n.c.
A980.6		<input type="checkbox"/> n.c.	A983.6		<input type="checkbox"/> n.c.
A980.7		<input type="checkbox"/> n.c.	A983.7		<input type="checkbox"/> n.c.
Zustimmtastermod.		Slot 3 / Byte 0			
	A981.0	<input type="checkbox"/> Zustimmtaster Beleuchtung für Taste +	A984.0	<input type="checkbox"/> n.c.	
	A981.1	<input type="checkbox"/> Zustimmtaster Beleuchtung für Taste -	A984.1	<input type="checkbox"/> n.c.	
	A981.2	<input type="checkbox"/> n.c.	A984.2	<input type="checkbox"/> n.c.	
	A981.3	<input type="checkbox"/> n.c.	A984.3	<input type="checkbox"/> n.c.	
	A981.4	<input type="checkbox"/> n.c.	A984.4	<input type="checkbox"/> n.c.	
	A981.5	<input type="checkbox"/> n.c.	A984.5	<input type="checkbox"/> n.c.	
	A981.6	<input type="checkbox"/> n.c.	A984.6	<input type="checkbox"/> n.c.	
	A981.7	<input type="checkbox"/> n.c.	A984.7	<input type="checkbox"/> n.c.	



EUC\MGB\MGB_PNC_R_114412.ema
Variant B
Overview
V2.0
==Safety==Safety_systems++MGB_PN+PNC-114412/114398.c

