

-A130
/113230.a.1
/113230.a.1

Eingänge



Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	E2467.0	<input type="checkbox"/> n.c.		E2470.0	<input type="checkbox"/> n.c.
	E2467.1	<input type="checkbox"/> n.c.		E2470.1	<input type="checkbox"/> n.c.
	E2467.2	<input type="checkbox"/> n.c.		E2470.2	<input type="checkbox"/> T (Türstellung)
	E2467.3	<input type="checkbox"/> n.c.		E2470.3	<input type="checkbox"/> R (Riegelstellung)
	E2467.4	<input type="checkbox"/> n.c.		E2470.4	<input type="checkbox"/> Z (Zuhaltung)
	E2467.5	<input type="checkbox"/> n.c.		E2470.5	<input type="checkbox"/> S91.1 Betriebsartenwahlschalter
	E2467.6	<input type="checkbox"/> n.c.		E2470.6	<input type="checkbox"/> S91.2 Betriebsartenwahlschalter
	E2467.7	<input type="checkbox"/> S90 Taster		E2470.7	<input type="checkbox"/> S91.3 Betriebsartenwahlschalter
	Slot 1 / Byte 1			Slot 5 / Byte 1	
E2468.0	<input type="checkbox"/> S92 Taster	E2471.0	<input type="checkbox"/> SK (T UND R)		
E2468.1	<input type="checkbox"/> n.c.	E2471.1	<input type="checkbox"/> ÜK (T UND R UND Z)		
E2468.2	<input type="checkbox"/> n.c.	E2471.2	<input type="checkbox"/> n.c.		
E2468.3	<input type="checkbox"/> S1 Schlüsselschalter	E2471.3	<input type="checkbox"/> n.c.		
E2468.4	<input type="checkbox"/> n.c.	E2471.4	<input type="checkbox"/> n.c.		
E2468.5	<input type="checkbox"/> n.c.	E2471.5	<input type="checkbox"/> n.c.		
E2468.6	<input type="checkbox"/> n.c.	E2471.6	<input type="checkbox"/> n.c.		
E2468.7	<input type="checkbox"/> n.c.	E2471.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
E2469.0	<input type="checkbox"/> Meldung liegt an. Profisafe				
E2469.1	<input type="checkbox"/> Meldung 274(4)				
E2469.2	<input type="checkbox"/> Meldung 272(1) oder 273(1)				
E2469.3	<input type="checkbox"/> Meldung 272(2) oder 273(2)				
E2469.4	<input type="checkbox"/> Meldung 272(6) oder 273(6)				
E2469.5	<input type="checkbox"/> n.c.				
E2469.6	<input type="checkbox"/> n.c.				
E2469.7	<input type="checkbox"/> Meldung 274(1)				

Ausgänge

Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	A1950.0	<input type="checkbox"/> n.c.		A1953.0	<input type="checkbox"/> Zuhaltemagnet - Steuerspannung ein
	A1950.1	<input type="checkbox"/> n.c.		A1953.1	<input type="checkbox"/> n.c.
	A1950.2	<input type="checkbox"/> n.c.		A1953.2	<input type="checkbox"/> n.c.
	A1950.3	<input type="checkbox"/> n.c.		A1953.3	<input type="checkbox"/> n.c.
	A1950.4	<input type="checkbox"/> n.c.		A1953.4	<input type="checkbox"/> n.c.
	A1950.5	<input type="checkbox"/> n.c.		A1953.5	<input type="checkbox"/> n.c.
	A1950.6	<input type="checkbox"/> n.c.		A1953.6	<input type="checkbox"/> n.c.
	A1950.7	<input type="checkbox"/> LED; H90		A1953.7	<input type="checkbox"/> n.c.
	Slot 1 / Byte 1			Slot 5 / Byte 1	
A1951.0	<input type="checkbox"/> LED; H92	A1954.0	<input type="checkbox"/> n.c.		
A1951.1	<input type="checkbox"/> n.c.	A1954.1	<input type="checkbox"/> n.c.		
A1951.2	<input type="checkbox"/> n.c.	A1954.2	<input type="checkbox"/> n.c.		
A1951.3	<input type="checkbox"/> n.c.	A1954.3	<input type="checkbox"/> n.c.		
A1951.4	<input type="checkbox"/> n.c.	A1954.4	<input type="checkbox"/> n.c.		
A1951.5	<input type="checkbox"/> n.c.	A1954.5	<input type="checkbox"/> n.c.		
A1951.6	<input type="checkbox"/> n.c.	A1954.6	<input type="checkbox"/> n.c.		
A1951.7	<input type="checkbox"/> Zuhaltemagnet	A1954.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
A1952.0	<input type="checkbox"/> Gerätediagnose: Meldung quittieren				
A1952.1	<input type="checkbox"/> Reset MGB Zuhaltemodul: Meldung quittieren				
A1952.2	<input type="checkbox"/> n.c.				
A1952.3	<input type="checkbox"/> n.c.				
A1952.4	<input type="checkbox"/> n.c.				
A1952.5	<input type="checkbox"/> n.c.				
A1952.6	<input type="checkbox"/> n.c.				
A1952.7	<input type="checkbox"/> n.c.				

EUCHNER | MGB

113230
MGB-L1HB-PNA-R
Zuhaltemodul 113612



EUC\MGB\MGB_PNA_R_114565.ema
Variant B
Overview
V1.0
==Safety=Safety_systems++MGB_PN+PNA-114565/113230.c

