

**EUCHNER** | MGB  
121840  
MGB-L2B-PNA-R

Page 10 of 10

-A122  
/121840.a.1  
/121840.a.1



## Eingänge

Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	E2285.0	<input type="checkbox"/> n.c.		E2288.0	<input type="checkbox"/> Not-Halt
	E2285.1	<input type="checkbox"/> n.c.		E2288.1	<input type="checkbox"/> n.c.
	E2285.2	<input type="checkbox"/> n.c.		E2288.2	<input type="checkbox"/> T (Türstellung)
	E2285.3	<input type="checkbox"/> n.c.		E2288.3	<input type="checkbox"/> R (Riegelstellung)
	E2285.4	<input type="checkbox"/> n.c.		E2288.4	<input type="checkbox"/> Z (Zuhaltung)
	E2285.5	<input type="checkbox"/> n.c.		E2288.5	<input type="checkbox"/> n.c.
	E2285.6	<input type="checkbox"/> n.c.		E2288.6	<input type="checkbox"/> n.c.
	E2285.7	<input type="checkbox"/> S8 Taster		E2288.7	<input type="checkbox"/> n.c.
	Slot 1 / Byte 1			Slot 5 / Byte 1	
E2286.0	<input type="checkbox"/> S9 Taster	E2289.0	<input type="checkbox"/> SK (T UND R)		
E2286.1	<input type="checkbox"/> n.c.	E2289.1	<input type="checkbox"/> ÜK (T UND R UND Z)		
E2286.2	<input type="checkbox"/> n.c.	E2289.2	<input type="checkbox"/> n.c.		
E2286.3	<input type="checkbox"/> n.c.	E2289.3	<input type="checkbox"/> n.c.		
E2286.4	<input type="checkbox"/> n.c.	E2289.4	<input type="checkbox"/> n.c.		
E2286.5	<input type="checkbox"/> n.c.	E2289.5	<input type="checkbox"/> n.c.		
E2286.6	<input type="checkbox"/> n.c.	E2289.6	<input type="checkbox"/> n.c.		
E2286.7	<input type="checkbox"/> n.c.	E2289.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
E2287.0	<input type="checkbox"/> Meldung liegt an. Profisafe				
E2287.1	<input type="checkbox"/> Meldung 274(4)				
E2287.2	<input type="checkbox"/> Meldung 272(1) oder 273(1)				
E2287.3	<input type="checkbox"/> n.c.				
E2287.4	<input type="checkbox"/> n.c.				
E2287.5	<input type="checkbox"/> n.c.				
E2287.6	<input type="checkbox"/> n.c.				
E2287.7	<input type="checkbox"/> Meldung 274(1)				

## Ausgänge

Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	A1862.0	<input type="checkbox"/> n.c.		A1865.0	<input type="checkbox"/> Zuhaltemagnet - Steuerspannung ein
	A1862.1	<input type="checkbox"/> n.c.		A1865.1	<input type="checkbox"/> n.c.
	A1862.2	<input type="checkbox"/> n.c.		A1865.2	<input type="checkbox"/> n.c.
	A1862.3	<input type="checkbox"/> n.c.		A1865.3	<input type="checkbox"/> n.c.
	A1862.4	<input type="checkbox"/> n.c.		A1865.4	<input type="checkbox"/> n.c.
	A1862.5	<input type="checkbox"/> n.c.		A1865.5	<input type="checkbox"/> n.c.
	A1862.6	<input type="checkbox"/> n.c.		A1865.6	<input type="checkbox"/> n.c.
	A1862.7	<input type="checkbox"/> LED; H8		A1865.7	<input type="checkbox"/> n.c.
	Slot 1 / Byte 1			Slot 5 / Byte 1	
A1863.0	<input type="checkbox"/> LED; H9	A1866.0	<input type="checkbox"/> n.c.		
A1863.1	<input type="checkbox"/> n.c.	A1866.1	<input type="checkbox"/> n.c.		
A1863.2	<input type="checkbox"/> LED; H7	A1866.2	<input type="checkbox"/> n.c.		
A1863.3	<input type="checkbox"/> n.c.	A1866.3	<input type="checkbox"/> n.c.		
A1863.4	<input type="checkbox"/> n.c.	A1866.4	<input type="checkbox"/> n.c.		
A1863.5	<input type="checkbox"/> n.c.	A1866.5	<input type="checkbox"/> n.c.		
A1863.6	<input type="checkbox"/> n.c.	A1866.6	<input type="checkbox"/> n.c.		
A1863.7	<input type="checkbox"/> Zuhaltemagnet	A1866.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
A1864.0	<input type="checkbox"/> Gerätediagnose: Meldung quittieren				
A1864.1	<input type="checkbox"/> Reset MGB Zuhaltemodul: Meldung quittieren				
A1864.2	<input type="checkbox"/> n.c.				
A1864.3	<input type="checkbox"/> n.c.				
A1864.4	<input type="checkbox"/> n.c.				
A1864.5	<input type="checkbox"/> n.c.				
A1864.6	<input type="checkbox"/> n.c.				
A1864.7	<input type="checkbox"/> n.c.				

**EUCHNER** | MGB  
121840  
MGB-L2B-PNA-R



EUC\MGB\MGB\_PNA\_R\_121928.ema  
Variant B  
Overview  
V1.0  
==Safety==Safety\_systems++MGB\_PN+PNA-121928/121840.c

