
-A136
/1138i4.a.1
/1138i4.a.1


Eingänge

Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	E2497.0	<input type="checkbox"/> n.c.		E2500.0	<input type="checkbox"/> n.c.
	E2497.1	<input type="checkbox"/> n.c.		E2500.1	<input type="checkbox"/> n.c.
	E2497.2	<input type="checkbox"/> n.c.		E2500.2	<input type="checkbox"/> T (Türstellung)
	E2497.3	<input type="checkbox"/> n.c.		E2500.3	<input type="checkbox"/> R (Riegelstellung)
	E2497.4	<input type="checkbox"/> n.c.		E2500.4	<input type="checkbox"/> Z (Zuhaltung)
	E2497.5	<input type="checkbox"/> n.c.		E2500.5	<input type="checkbox"/> S91.1 Betriebsartenwahlschalter
	E2497.6	<input type="checkbox"/> n.c.		E2500.6	<input type="checkbox"/> S91.2 Betriebsartenwahlschalter
	E2497.7	<input type="checkbox"/> S90 Taster		E2500.7	<input type="checkbox"/> S91.3 Betriebsartenwahlschalter
	Slot 1 / Byte 1			Slot 5 / Byte 1	
E2498.0	<input type="checkbox"/> S92 Taster	E2501.0	<input type="checkbox"/> SK (T UND R)		
E2498.1	<input type="checkbox"/> n.c.	E2501.1	<input type="checkbox"/> ÜK (T UND R UND Z)		
E2498.2	<input type="checkbox"/> n.c.	E2501.2	<input type="checkbox"/> n.c.		
E2498.3	<input type="checkbox"/> S1 Schlüsselschalter	E2501.3	<input type="checkbox"/> n.c.		
E2498.4	<input type="checkbox"/> n.c.	E2501.4	<input type="checkbox"/> n.c.		
E2498.5	<input type="checkbox"/> n.c.	E2501.5	<input type="checkbox"/> n.c.		
E2498.6	<input type="checkbox"/> n.c.	E2501.6	<input type="checkbox"/> n.c.		
E2498.7	<input type="checkbox"/> n.c.	E2501.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
E2499.0	<input type="checkbox"/> Meldung liegt an. Profisafe				
E2499.1	<input type="checkbox"/> Meldung 274(4)				
E2499.2	<input type="checkbox"/> Meldung 272(1) oder 273(1)				
E2499.3	<input type="checkbox"/> Meldung 272(2) oder 273(2)				
E2499.4	<input type="checkbox"/> Meldung 272(6) oder 273(6)				
E2499.5	<input type="checkbox"/> n.c.				
E2499.6	<input type="checkbox"/> n.c.				
E2499.7	<input type="checkbox"/> Meldung 274(1)				

Ausgänge

Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	A1980.0	<input type="checkbox"/> n.c.		A1983.0	<input type="checkbox"/> Zuhaltemagnet - Steuerspannung ein
	A1980.1	<input type="checkbox"/> n.c.		A1983.1	<input type="checkbox"/> n.c.
	A1980.2	<input type="checkbox"/> n.c.		A1983.2	<input type="checkbox"/> n.c.
	A1980.3	<input type="checkbox"/> n.c.		A1983.3	<input type="checkbox"/> n.c.
	A1980.4	<input type="checkbox"/> n.c.		A1983.4	<input type="checkbox"/> n.c.
	A1980.5	<input type="checkbox"/> n.c.		A1983.5	<input type="checkbox"/> n.c.
	A1980.6	<input type="checkbox"/> n.c.		A1983.6	<input type="checkbox"/> n.c.
	A1980.7	<input type="checkbox"/> LED; H90		A1983.7	<input type="checkbox"/> n.c.
	Slot 1 / Byte 1			Slot 5 / Byte 1	
A1981.0	<input type="checkbox"/> LED; H92	A1984.0	<input type="checkbox"/> n.c.		
A1981.1	<input type="checkbox"/> n.c.	A1984.1	<input type="checkbox"/> n.c.		
A1981.2	<input type="checkbox"/> n.c.	A1984.2	<input type="checkbox"/> n.c.		
A1981.3	<input type="checkbox"/> n.c.	A1984.3	<input type="checkbox"/> n.c.		
A1981.4	<input type="checkbox"/> n.c.	A1984.4	<input type="checkbox"/> n.c.		
A1981.5	<input type="checkbox"/> n.c.	A1984.5	<input type="checkbox"/> n.c.		
A1981.6	<input type="checkbox"/> n.c.	A1984.6	<input type="checkbox"/> n.c.		
A1981.7	<input type="checkbox"/> Zuhaltemagnet	A1984.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
A1982.0	<input type="checkbox"/> Gerätediagnose: Meldung quittieren				
A1982.1	<input type="checkbox"/> Reset MGB Zuhaltemodul: Meldung quittieren				
A1982.2	<input type="checkbox"/> n.c.				
A1982.3	<input type="checkbox"/> n.c.				
A1982.4	<input type="checkbox"/> n.c.				
A1982.5	<input type="checkbox"/> n.c.				
A1982.6	<input type="checkbox"/> n.c.				
A1982.7	<input type="checkbox"/> n.c.				

EUCHNER | MGB
113614
MGB-L0B-PNA-R



EUC\MGB\MGB_PNA_R_114565.ema
Variant B
Overview
V1.0
==Safety=Safety_systems++MGB_PN+PNA-114565/113614.c

