


EUC\MGB\MGB\_PNA\_L\_114565.ema

### Variant A

## Multi-line

V1.0

==Safety==Safety\_systems++MGB\_PN+PNA-114565/113613.a




EUC\MGB\MGB\_PNA\_L\_114565.ema

### Variant B

Multi-line

V1.0

==Safety==Safety\_systems++MGB\_PN+PNA-114565/113613.a



			Datum	21.07.16	<div style="text-align: center; font-size: 2em; font-weight: bold; color: red;">EUCHNER</div>		Artikelnummer:	<div style="font-size: 1.5em; font-weight: bold; color: green;">113613.a</div>	Typ: Eplan Makro	= Safety_systems
			Bearb.	avara					++ MGB_PN	
			Gepr							
Änderung	Datum	Name	Urspr		Ersatz von	Ersetzt durch				

-A135  
/113d13.a.1  
/113q13.a.1


## Eingänge

Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	E2492.0	<input type="checkbox"/> n.c.		E2495.0	<input type="checkbox"/> n.c.
	E2492.1	<input type="checkbox"/> n.c.		E2495.1	<input type="checkbox"/> n.c.
	E2492.2	<input type="checkbox"/> n.c.		E2495.2	<input type="checkbox"/> T (Türstellung)
	E2492.3	<input type="checkbox"/> n.c.		E2495.3	<input type="checkbox"/> R (Riegelstellung)
	E2492.4	<input type="checkbox"/> n.c.		E2495.4	<input type="checkbox"/> Z (Zuhaltung)
	E2492.5	<input type="checkbox"/> n.c.		E2495.5	<input type="checkbox"/> S91.1 Betriebsartenwahlschalter
	E2492.6	<input type="checkbox"/> n.c.		E2495.6	<input type="checkbox"/> S91.2 Betriebsartenwahlschalter
	E2492.7	<input type="checkbox"/> S90 Taster		E2495.7	<input type="checkbox"/> S91.3 Betriebsartenwahlschalter
	Slot 1 / Byte 1			Slot 5 / Byte 1	
E2493.0	<input type="checkbox"/> S92 Taster	E2496.0	<input type="checkbox"/> SK (T UND R)		
E2493.1	<input type="checkbox"/> n.c.	E2496.1	<input type="checkbox"/> ÜK (T UND R UND Z)		
E2493.2	<input type="checkbox"/> n.c.	E2496.2	<input type="checkbox"/> n.c.		
E2493.3	<input type="checkbox"/> S1 Schlüsselschalter	E2496.3	<input type="checkbox"/> n.c.		
E2493.4	<input type="checkbox"/> n.c.	E2496.4	<input type="checkbox"/> n.c.		
E2493.5	<input type="checkbox"/> n.c.	E2496.5	<input type="checkbox"/> n.c.		
E2493.6	<input type="checkbox"/> n.c.	E2496.6	<input type="checkbox"/> n.c.		
E2493.7	<input type="checkbox"/> n.c.	E2496.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
E2494.0	<input type="checkbox"/> Meldung liegt an. Profisafe				
E2494.1	<input type="checkbox"/> Meldung 274(4)				
E2494.2	<input type="checkbox"/> Meldung 272(1) oder 273(1)				
E2494.3	<input type="checkbox"/> Meldung 272(2) oder 273(2)				
E2494.4	<input type="checkbox"/> Meldung 272(6) oder 273(6)				
E2494.5	<input type="checkbox"/> n.c.				
E2494.6	<input type="checkbox"/> n.c.				
E2494.7	<input type="checkbox"/> Meldung 274(1)				

## Ausgänge

Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	A1975.0	<input type="checkbox"/> n.c.		A1978.0	<input type="checkbox"/> Zuhaltemagnet - Steuerspannung ein
	A1975.1	<input type="checkbox"/> n.c.		A1978.1	<input type="checkbox"/> n.c.
	A1975.2	<input type="checkbox"/> n.c.		A1978.2	<input type="checkbox"/> n.c.
	A1975.3	<input type="checkbox"/> n.c.		A1978.3	<input type="checkbox"/> n.c.
	A1975.4	<input type="checkbox"/> n.c.		A1978.4	<input type="checkbox"/> n.c.
	A1975.5	<input type="checkbox"/> n.c.		A1978.5	<input type="checkbox"/> n.c.
	A1975.6	<input type="checkbox"/> n.c.		A1978.6	<input type="checkbox"/> n.c.
	A1975.7	<input type="checkbox"/> LED; H90		A1978.7	<input type="checkbox"/> n.c.
	Slot 1 / Byte 1			Slot 5 / Byte 1	
A1976.0	<input type="checkbox"/> LED; H92	A1979.0	<input type="checkbox"/> n.c.		
A1976.1	<input type="checkbox"/> n.c.	A1979.1	<input type="checkbox"/> n.c.		
A1976.2	<input type="checkbox"/> n.c.	A1979.2	<input type="checkbox"/> n.c.		
A1976.3	<input type="checkbox"/> n.c.	A1979.3	<input type="checkbox"/> n.c.		
A1976.4	<input type="checkbox"/> n.c.	A1979.4	<input type="checkbox"/> n.c.		
A1976.5	<input type="checkbox"/> n.c.	A1979.5	<input type="checkbox"/> n.c.		
A1976.6	<input type="checkbox"/> n.c.	A1979.6	<input type="checkbox"/> n.c.		
A1976.7	<input type="checkbox"/> Zuhaltemagnet	A1979.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
A1977.0	<input type="checkbox"/> Gerätediagnose: Meldung quittieren				
A1977.1	<input type="checkbox"/> Reset MGB Zuhaltemodul: Meldung quittieren				
A1977.2	<input type="checkbox"/> n.c.				
A1977.3	<input type="checkbox"/> n.c.				
A1977.4	<input type="checkbox"/> n.c.				
A1977.5	<input type="checkbox"/> n.c.				
A1977.6	<input type="checkbox"/> n.c.				
A1977.7	<input type="checkbox"/> n.c.				

**EUCHNER** | MGB  
113613  
MGB-L1B-PNA-L



EUC\MGB\MGB\_PNA\_L\_114565.ema  
Variant B  
Overview  
V1.0  
==Safety=Safety\_systems++MGB\_PN+PNA-114565/113613.c

