

EUCHNER | MGB
121846
MGB-L1B-PNA-L

-A128
/121846.a.1
/121846.a.1




Eingänge

Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	E2315.0	<input type="checkbox"/> n.c.		E2318.0	<input type="checkbox"/> Not-Halt
	E2315.1	<input type="checkbox"/> n.c.		E2318.1	<input type="checkbox"/> n.c.
	E2315.2	<input type="checkbox"/> n.c.		E2318.2	<input type="checkbox"/> T (Türstellung)
	E2315.3	<input type="checkbox"/> n.c.		E2318.3	<input type="checkbox"/> R (Riegelstellung)
	E2315.4	<input type="checkbox"/> n.c.		E2318.4	<input type="checkbox"/> Z (Zuhaltung)
	E2315.5	<input type="checkbox"/> n.c.		E2318.5	<input type="checkbox"/> n.c.
	E2315.6	<input type="checkbox"/> n.c.		E2318.6	<input type="checkbox"/> n.c.
	E2315.7	<input type="checkbox"/> S8 Taster		E2318.7	<input type="checkbox"/> n.c.
	Slot 1 / Byte 1			Slot 5 / Byte 1	
E2316.0	<input type="checkbox"/> S9 Taster	E2319.0	<input type="checkbox"/> SK (T UND R)		
E2316.1	<input type="checkbox"/> n.c.	E2319.1	<input type="checkbox"/> ÜK (T UND R UND Z)		
E2316.2	<input type="checkbox"/> n.c.	E2319.2	<input type="checkbox"/> n.c.		
E2316.3	<input type="checkbox"/> n.c.	E2319.3	<input type="checkbox"/> n.c.		
E2316.4	<input type="checkbox"/> n.c.	E2319.4	<input type="checkbox"/> n.c.		
E2316.5	<input type="checkbox"/> n.c.	E2319.5	<input type="checkbox"/> n.c.		
E2316.6	<input type="checkbox"/> n.c.	E2319.6	<input type="checkbox"/> n.c.		
E2316.7	<input type="checkbox"/> n.c.	E2319.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
E2317.0	<input type="checkbox"/> Meldung liegt an. Profisafe				
E2317.1	<input type="checkbox"/> Meldung 274(4)				
E2317.2	<input type="checkbox"/> Meldung 272(1) oder 273(1)				
E2317.3	<input type="checkbox"/> n.c.				
E2317.4	<input type="checkbox"/> n.c.				
E2317.5	<input type="checkbox"/> n.c.				
E2317.6	<input type="checkbox"/> n.c.				
E2317.7	<input type="checkbox"/> Meldung 274(1)				

Ausgänge

Profinet	Slot 1 / Byte 0		PROFIsafe	Slot 5 / Byte 0	
	A1892.0	<input type="checkbox"/> n.c.		A1895.0	<input type="checkbox"/> Zuhaltemagnet - Steuerspannung ein
	A1892.1	<input type="checkbox"/> n.c.		A1895.1	<input type="checkbox"/> n.c.
	A1892.2	<input type="checkbox"/> n.c.		A1895.2	<input type="checkbox"/> n.c.
	A1892.3	<input type="checkbox"/> n.c.		A1895.3	<input type="checkbox"/> n.c.
	A1892.4	<input type="checkbox"/> n.c.		A1895.4	<input type="checkbox"/> n.c.
	A1892.5	<input type="checkbox"/> n.c.		A1895.5	<input type="checkbox"/> n.c.
	A1892.6	<input type="checkbox"/> n.c.		A1895.6	<input type="checkbox"/> n.c.
	A1892.7	<input type="checkbox"/> LED; H8		A1895.7	<input type="checkbox"/> n.c.
	Slot 1 / Byte 1			Slot 5 / Byte 1	
A1893.0	<input type="checkbox"/> LED; H9	A1896.0	<input type="checkbox"/> n.c.		
A1893.1	<input type="checkbox"/> n.c.	A1896.1	<input type="checkbox"/> n.c.		
A1893.2	<input type="checkbox"/> LED; H7	A1896.2	<input type="checkbox"/> n.c.		
A1893.3	<input type="checkbox"/> n.c.	A1896.3	<input type="checkbox"/> n.c.		
A1893.4	<input type="checkbox"/> n.c.	A1896.4	<input type="checkbox"/> n.c.		
A1893.5	<input type="checkbox"/> n.c.	A1896.5	<input type="checkbox"/> n.c.		
A1893.6	<input type="checkbox"/> n.c.	A1896.6	<input type="checkbox"/> n.c.		
A1893.7	<input type="checkbox"/> Zuhaltemagnet	A1896.7	<input type="checkbox"/> n.c.		
Slot 1 / Byte 2					
A1894.0	<input type="checkbox"/> Gerätediagnose: Meldung quittieren				
A1894.1	<input type="checkbox"/> Reset MGB Zuhaltemodul: Meldung quittieren				
A1894.2	<input type="checkbox"/> n.c.				
A1894.3	<input type="checkbox"/> n.c.				
A1894.4	<input type="checkbox"/> n.c.				
A1894.5	<input type="checkbox"/> n.c.				
A1894.6	<input type="checkbox"/> n.c.				
A1894.7	<input type="checkbox"/> n.c.				

EUCHNER | MGB
121846
MGB-L1B-PNA-L



121846.b

EUC\MGB\MGB_PNA_L_121928.ema
Variant B
Overview
V1.0
==Safety==Safety_systems++MGB_PN+PNA-121928/121846.c

